

Creating a New Program


Note: Must be connected to the PTX Transmitter via Bluetooth before proceeding.

1. From the HOME page, press PTX CLASSIC
2. Once on the PTX CLASSIC page, press MENU
3. Select PROGRAMS
4. Select NEW
5. Enter Program name DRILL followed by the number

Note:

- DRILL must be capitalized with no space between the letter and number; e.g., DRILL1, DRILL2...
- Must be between 1-9

6. Set Time
 - Enter how long the program should run (in seconds).
7. SET NUMBER OF TARGETS
 - Enter how many targets you are controlling
8. Press the checkmark in the upper right corner




Understanding the Program Table

Each row = 1 second in the program.
 Each column = A target (1, 2, 3, etc.).

The first column lets you send a command to ALL targets.

Add Commands

1. Tap a cell to edit it and a drop down menu will appear
2. Choose one of these commands:
 - FRIEND
 - EDGE
 - FOE
 - DOWN




Note: Each cell starts as NONE, meaning no change

Add More Time or Targets

Tap +TIME to add more seconds.

Tap +TARGETS to add more targets.

TIP: If you use an ALL command, make sure the rest of the row is set to NONE.




Test & Save

Turn targets ON.

Tap RUN to test the program.

Tap outside the table to deselect cells.

Tap SAVE, then BACK to return.



Note: To delete DRILLS go to the tablets File folder then press **Internal Storage > Documents > ATS.UTC**. You should see your DRILLS listed here. To delete you must long press on the drill you wish to delete then press delete off the bottom menu. This will remove your drills from the app.